
world
OuterTrackers
InnerTrackers
Vertex
OuterTrackerEndcapSupport
OuterTrackerBarrelSupport
OuterTrackerBarrel
InnerTrackerBarrel
InnerTrackerBarrelSupport
BeampipeShellX
InnerTrackerEndcapSupport
InnerTrackerInterlink
InnerTrackerVertexCable
VertexVerticalCable
VertexBarrel
VertexEndcap
OuterTrackerEndcapSupport_layerX_pos
OuterTrackerEndcapSupport_layerX_neg
OuterTrackerEndcap
InnerTrackerEndcap
layerX
BeampipeShellX_layerX_pos
BeampipeShellX_layerX_neg
InnerTrackerEndcapSupport_layerX_pos
InnerTrackerEndcapSupport_layerX_neg
VertexVerticalCable_layerX_pos
VertexVerticalCable_layerX_neg
layer_X
layerX_moduleX_sensorX_pos
layerX_moduleX_sensorX_neg
moduleXsensorX
VertexBarrel_layerX_ladderX
componentX